

**SMART TV
RM-20GA+**

1. Pentru deconectarea telecomenzii

Magic Remote: Apăsați și mențineți apăsată butoanele /HOME și/BACK în același timp până când indicatorul luminos se aprinde pentru a șterge informațiile de asociere ale fostei telecomenzi cu televizorul existent.

2. Pentru a asocia telecomanda Magic

Remote: Apăsați butonul Voce, televizorul va indica să apăsați butonul Rotiță (OK). 

Notă: vă rugăm să operați telecomanda conform secvenței de mai sus: deconectați telecomanda magică în primul rând.

English

1. To unpair the Magic Remote:

Press and hold /HOME and /BACK buttons at the same time till the indicator light is on in order to clear the pairing information of the former remote with the existing TV.

2. To pair the Magic Remote:

Press Voice Button, the TV will indicate to press the Wheel (OK) Button. 

Noted: please operate the remote according to above sequence: unpair the magic remote first of all.

Specificații

Distanță operabilă:
Mai mult de 8 metri

Cerințe suplimentare:
DC 3V

Tip baterie:
baterii AA de 1,5 V

Specifications

Operable distance:
More than 8 metres

Power toquirements:
DC 3V

Battery type:
1.5V AA batttries

Distribuitor

Sunnysoft s.r.o.
Kovanecká 2390/1a
190 00 Praga 9
Republica Cehă
www.sunnysoft.cz